

vaakakoneen taulukko

Suoja nro:	a	b	c	d	e
11	109	250	70	145	160
14	129	280	70	145	160
16	154	280	70	145	160
18	173	320	75	145	180
20	193	380	75	145	180
22	219	400	90	210	210
26	259	500	90	210	210
32	300	590	135	250	290
36	335	700	135	250	290
40	382	750	170	330	560
45	445	800	170	330	590
50	497	900	220	400	590
56	557	1200	220	450	630
63	630	1570	230	480	690
71	728	1650	330	550	830
80	825	1890	400	600	870
101	1040	1800	440	610	1000
105	1040	2050	440	610	1000
109	1040	2300	440	610	1000

